

## 1- نوصل كبل الشبكة بين الراوتر واللابتوب الموجود لدينا.

تأكد أن كبل الشبكة الموصول مع اللاقط موصول في مدخل WAN




## 2- نقوم بفتح أي متصفح موجود على اللابتوب.



## 3- نقوم بادخال الـ IP التالي 192.168.1.1 في مربع البحث كما هو موضح في الصورة

ملاحظة : IP الدخول لاعدادات الراوتر يكون مكتوب على اللصاقة الموجودة خلف الراوتر



2054

[www.runnet.sy](http://www.runnet.sy)

4- ندخل اسم المستخدم وكلمة المرور غالباً تكون admin  
admin  
ثم نقوم بالضغط على خيار Setup Wizard

**D-Link**

DSL-124 // SETUP ADVANCED MAINTENANCE STATUS HELP

Wizard  
Local Network  
Internet Setup  
Wireless Setup  
Time and Date

**SETTING UP YOUR INTERNET**

There are two ways to set up your Internet connection. You can use the Web-based Internet Connection Setup Wizard or you can manually configure the connection.

Please make sure you have your ISP's connection settings first if you choose manual setup.

**INTERNET CONNECTION WIZARD**

You can use this wizard for assistance and quick connection of your new D-Link Router to the Internet. You will be presented with step-by-step instructions in order to get your Internet connection up and running. Click the button below to begin.

[Setup Wizard](#)

**Note:** Before launching the wizard, please ensure you have correctly followed the steps outlined in the Quick Installation Guide included with the router.

**Helpful Hints...**

First time users are recommended to run the **Setup Wizard**. Click the [Setup Wizard](#) button and you will be guided step by step through the process of setting up your ADSL connection.

If you consider yourself an advanced user or have configured a router before, click **Setup->Internet Setup** to input all the settings manually.

[More...](#)

5- نقوم بادخال اسم المستخدم وكلمة السر التي تم ارسالها من قبل المزود وفق الاتي :

**D-Link**

1 → 2 → **STEP 3: SETUP INTERNET CONNECTION** → 4 → 5

Please select your WAN Physical Type.

WAN Physical Type : Ethernet WAN

**ISP**

Protocol : PPPoE

**PPPoE**

Please enter your Username and Password. Please enter the information exactly as shown taking note of upper and lower cases. Click "Next" to continue.

Username : ahmad22@runnet.sy  
Password : كلمة المرور  
Confirm Password : تأكيد كلمة المرور

Back Next Cancel

## 6- نقوم بضبط شبكة الـ WIFI وفق الاتي :

### D-Link

1 → 2 → 3 → **STEP 4: CONFIGURE WIRELESS NETWORK** → 5

Your wireless network is enabled by default. You can simply uncheck it to disable it and click "Next" to skip configuration of wireless network.

**Enable Your Wireless Network**

Your wireless network needs a name so it can be easily recognized by wireless clients. For security purposes, it is highly recommended to change the pre-configured network name.

**Wireless Network Name (SSID) :**  (1~32 characters)

Select "Visible" to publish your wireless network and SSID can be found by wireless clients, or select "Invisible" to hide your wireless network so that users need to manually enter SSID in order to connect to your wireless network.

**Visibility Status :**  Visible  Invisible

In order to protect your network from hackers and unauthorized users, it is highly recommended you choose one of the following wireless network security settings.

**Security Level :**

None  WEP  WPA-PSK  WPA2-PSK

**Security Mode:** WPA-PSK  
Select this option if your wireless adapters support WPA-PSK.

Now, please enter your wireless security key.

**WPA2 Pre-Shared Key :**

(8-63 characters, such as a~z, A~Z, or 0~9, i.e. '%Fortress123&')

**Note:** You will need to enter the same key here into your wireless clients in order to enable proper wireless connection.